


How to use the microphones

Hand-held

Switch to **RED** and point at your mouth, switch off to **BLACK**

Red light will flash once



Do not use the green standby setting

Tie-clip

Wear in the middle and high on your chest
Then switch to **ON**, and switch **OFF** afterwards


Red light will flash once



Too low
(will cause ringing or feedback)



Off centre
(will cause changes in volume)



After the service, put the microphones back on recharge

Plug the cables from the wireless receiver into the bottom of the microphones.

Do not straighten the antennae on the receiver. They are meant to be at 90° to each other.



Red lights FLASH when recharging



Fire hazard

Do not put normal batteries in the microphones. If normal batteries are recharged it can cause fires.